


# TRIUMPH-B-1 Instruction Manual



1 6Pcs	2 ST3.5X30 6Pcs	3 1Pc
4 6Pcs	5 1Pc	6 1Pc
7 1Pc	8 1Pc	9 1Pc
10 1Pc	11 1Pc	12 1Pc
13 R L 2Pcs	14 1Pc	15 1Pc
16 1Pc	17 1Pc	18 2Pcs
19 R L 2Pcs	20 R L 2Pcs	21 1Pc
22 1Pc	23 1Pc	24 ST3.5X30 4Pcs
		25 1Pc

TOOLS  
REQUIRED

